

## A5s – Android – 飯店模式

- 1)請先記下 A5s 的無線網路名稱，在 A5s 的背面 SSID：Tenda\_xxxxxx
- 2)將 A5s 插上電源，接上來源端的網路線到 A5s
- 3)拿出智慧型手機

進入設定，點 **無線與網路**



Wi-Fi 打勾勾  
點 Wi-Fi 設定



開啟 Wi-Fi 設定後，會搜尋到 Tenda\_xxxxxx 的名稱



點選 A5s 的 Tenda\_xxxxxx 的名稱，點連線



1. 密碼： admin
2. 輸入完密碼，按登入



1. 選 家用模式： PPPoE(ADSL 撥號)
2. 確定後，按下一步



1. SSID：Tenda\_xxxxxx ←是您的無線網路名稱(wifi)，可以做更改，不能輸入中文。
2. 加密模式： WPA-PSK ；演算法：●AES
3. 金鑰(密碼)：\_\_\_\_\_ ←這裡是您的無線網路(WIFI)密碼，請輸入最少 8 個字元，請勿輸入中文。
4. 確定後，按下一步

The screenshot shows the '設定精靈' (Wizard) page for wireless security. The SSID is 'Tenda\_4FB2E0', the channel is 'Auto', the encryption mode is 'WPA-PSK', and the algorithm is 'AES'. The password is '12345678'. The '下一步' (Next) button is highlighted with a red box and the number 4.

1 SSID: Tenda\_4FB2E0

2 加密模式: WPA-PSK

3 金鑰(密碼): 12345678

4 下一步

1. 以中華電信為範例，帳號、密碼是申請所配發的卡片背面上的帳號、密碼。PS帳號請加上@hinet.net
2. 確定輸入無誤，按下一步

The screenshot shows the '設定精靈' (Wizard) page for WAN settings. The username is '76543210@hinet.net' and the password is '12345678abc'. The MAC address is 'C8:3A:35:4F:B2:E5'. The '下一步' (Next) button is highlighted with a red box and the number 2.

1 使用者名稱(帳號): 76543210@hinet.net

密碼: 12345678abc

設定路由器WAN埠的MAC位址:

MAC位址: C8:3A:35:4F:B2:E5 (例如:c8:3a:35:3c:10:b8)

2 下一步




直接按，完成



The screenshot shows the Tenda web management interface. The top navigation bar includes '設定精靈' (Wizard), '系統狀態' (System Status), '基本設定' (Basic Settings), '無線網路設定' (Wireless Network Settings), '管理規則設定' (Management Rule Settings), '進階設定' (Advanced Settings), '頻寬管理' (Bandwidth Management), and '系統工具' (System Tools). The '設定精靈' page is active, displaying '設定完成' (Setup Complete) in the center. Below this text are two buttons: '上一步' (Previous Step) and '完成' (Finish). The '完成' button is highlighted with a red rectangular box. On the right side, there is a '說明資訊' (Information) section with three paragraphs of text explaining different connection modes: 飯店模式 (Hotel Mode), 家用模式 (Home Mode), and WDS模式 (WDS Mode).

按完成後，此時，會重新啟動



The screenshot shows the Tenda web management interface during a restart process. A central dialog box contains a progress bar with a yellow and orange striped pattern, and the text '設備正在重新啟動，請稍後... 51%' (Device is restarting, please wait... 51%). The background interface is dimmed, showing the same navigation bar and '設定精靈' page as in the previous screenshot.

重新啟動後會斷線。

需要重新連線無線網路，建議先做下底下步驟，點藍框框的無網符號



點 清除



重新搜尋無線網路名稱，輸入密碼，即可。

